

First Time Set-Up Instructions



Take a new Drain Insert and place it in the waste trap.



Press down on the drain insert until you feel and hear a slight popping sound. The insert must be tight.



Pour about 30 oz. (1L) of water over the Drain Insert. Then slowly pour the **entire contents of the Blue Seal Odor Barrier** onto the Drain Insert. Wipe clean. The Water Matrix - ZeroFlush Urinal is now ready for use.

Daily Cleaning Instructions



Remove debris.



Spray on **Matrix Enviro-Clean** on the inside of the urinal bowl, and let stand.



Use **Matrix Enviro-Clean** to spray around the urinal, and wipe clean.